





S2*

S3*




S6*


S4*




1




W7a*



18a



18b



19




23c

23d

23c

23d




W10*

WYCIĄĆ




K5




K6P




K6L




K6a




3



4



5




6



NR21




2100



7




7aL



7aP

Wyciąć po sklejeniu

20




21




8P

8L



16L



16P